


# REPAIR PARTS

SEARS TRIMMER MODEL 358.795800



**WARNING**

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015886	Screw	24.	530016014	Screw
2.	530015805	Screw-alignment	25.	530096251	Assy.-Driveshaft
3.	530057983	Throttle hsg-right	26.	530096203	Shaft-Flex Drive
4.	530016326	Screw-Cable Retention	27.	530015940	Screw
5.	530057984	Throttle hsg-left	28.	530058563	Bracket-Clamp
6.	530058843	Assy-Front Wire	29.	530015940	Screw
7.	530069572	Kit-Switch	30.	530057987	Clamp-Harness (lower)
8.	530057986	Clamp-Harness (upper)	31.	530058759	Lever-Throttle
9.	530058563	Bracket-Clamp	32.	530016152	Wingnut
10.	530015886	Screw	33.	530052285	Limiter-Line
11.	530071806	Assy.-Handlebar (incl. grip, cap, decal)	34.	530015814	Screw
12.	530058765	Clamp-Handlebar	35.	530015820	Bolt
13.	530057554	Bracket-Shield	36.	530071765	Kit-Shield Assy. (incl. 33,34)
14.	530094408	Shoulder Strap	37.	71-85740	Head-Cutting
15.	530096100	Assy-Gearbox	38.	---	Tube - Twisted Line
16.	530016312	Screw		71-85908	Red Line
17.	530071383	Kit-Metal Shield		71-85909	Black Line
18.	530095815	Dust cup	39.	530096039	Plate-Glide
19.	---	Assy-Blade			
	530055892	4 Point Blade			Not Shown
	530054867	8 Point Blade		530164363	Operator Manual
20.	530095816	Washer		530055573	Decal-Shaft Warning
21.	530016240	Washer-Belleville		530056335	Decal-Blade Direction
22.	530015793	Nut-Flange		530031159	Wrench-Hex (5/32")
23.	530016224	Screw		530055573	Decal-Start Instruction

# REPAIR PARTS

## WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

SEARS TRIMMER MODEL 358.795800



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530047721	Bulb-Purge	23.	530015875	Screw-Retainer	48.	530055122	Assy-Clutch
2.	530071717	Kit-Choke Lever	24.	530055492	Isolator-Tank	49.	530028799	Drum-Clutch
3.	530015843	Screw-tank	25.	530054941	Ret.-Tank	50.	530010960	Assy-Conn. Rod
4.	530049386	Cap-Fuel w/ret.	26.	530054834	Handle-Starter	51.	530015162	Ret.-Piston pin
5.	530014362	Assy-Fuel pickup	27.	530071325	Kit-Rope	52.	530025875	Ring-Piston
6.	530071404	Kit-Fuel line	28.	530032103	Bearing-Inner	53.	530069275	Kit-Piston (incl. 51,52)
7.	530069216	Kit-Fuel/Purge line	29.	530019158	Retainer	54.	530071401	Gasket-Cylinder(kit)
8.	530015775	Screw	30.	530032102	Seal	55.	530058846	Gasket-Cylinder(kit)
9.	530054935	Cover-Air box	31.	530015789	Bearing-Outer	56.	530069310	Assy-Leadwire
10.	530054946	Filter-Air	32.	530028807	Ret.-Crankshaft	57.	530058957	Kit-Muffler
11.	530015849	Screw-Carb.	33.	530012514	Assy-Crankshaft	58.	530036409	Shield
12.	530054934	Box-Air	34.	530071685	Assy-Crankcase	59.	530071582	Spring-Muffler
13.	530071637	Assy-Carb(WT628)	35.	530071685	Assy-C'case/C'sft (incl.28-34)	60.	71-85920	Kit-Cylinder
(Note: Repair kits are not available for this carburetor)			36.	530071402	Kit-Flywheel Assy.	61.	530001624	Plug-Spark(RCJ-6Y)
14.	530071401	Gasket-Carb.(kit)	37.	530016030	Washer	62.	530039218	Bolt-Cyl. 1/4-20"
15.	530055320	Assy-Fuel Tank	38.	530055620	Spacer	63.	530016357	Module-Ignition
16.	530015771	Screw-Crankcase	39.	530015775	Screw-Baffle	64.	530071401	Screw-Module
17.	530015952	Screw-Shroud	40.	530054939	Plate-Baffle	65.	530058962	Kit-Gasket (incl. 14,19, 54)
18.	530058797	Shroud	41.	530016391	Screw-Rope			Assy-Throttle cable
19.	530071401	O-ring-Shroud (kit)	42.	530071399	Kit-Pulley(incl.41)			
20.	530027593	Valve-Reed	43.	530042086	Spring-Starter			
21.	530054596	Stop-Reed	44.	530019182	Grommet			
22.	530016064	Screw-Reed stop	45.	530015810	Screw-F/hsg.			
			46.	530059278	Assy-Fan Housing			
			47.	530094189	Washer			