


REPAIR PARTS

SEARS CHAINSAW MODEL 944.414370

WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.




Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530047963	Assy.- Isolator	30.	530015127	Washer-Flywheel	57.	530071259	Kit - Oil Pump (incl. 58,59,61)
2.	530047608	Limiter Strap	31.	530039187	Assy-Flywheel	58.	530037820	Gear-Worm Spring
3.	530042082	Spring- Isolator	32.	530047192	Assy-Fuel Cap	59.	530049477	Elbow-Oil Pickup
4.	530015158	Washer	33.	530023877	Fitting-fuel line	60.	530016064	Screw
5.	530016018	Screw	34.	530069216	Kit-Fuel line (large)	61.	530019206	Seal Block
6.	530015843	Screw	35.	530016149	Spring-Switch	62.	530047663	Assy-Oil Pick-up (Incl. 63,64)
7.	530047583	Front Handle	36.	530015775	Screw	63.	530038373	Pick-up Oiler
8.	530015940	Screw	37.	530047581	Cover-Rear Handle	64.	530056533	Filter-Oil
9.	530015814	Screw	38.	530015886	Screw			
10.	71-3629	Chain-16"	39.	530015906	Screw			
11.	71-36596	EZ Adjust Bar-16"	40.	530036098	Throttle Lockout			
12.	530015917	Nut-Bar Mounting	41.	530036097	Trigger-Throttle			
13.	530055113	Assy.-Chain Brake	42.	530047582	Handle-Rear			
14.	530016132	Screw	43.	530015814	Screw			
15.	530038238	Plate-Bar Mount.	44.	530053274	Assy Isolator-lower			
16.	530015814	Screw	45.	530071385	Kit-Isolator (Upper)			
17.	530029850	Chain Catcher	46.	530015875	Screw			
18.	530016133	Bolt-Bar	47.	530042082	Spring-Isolator			
19.	530010846	Assy-Oil Cap	48.	530057473	Lever-Switch			
20.	530071666	Kit-Oil Vent	49.	530057474	Lever-Choke			
21.	530016134	Nut-Flywheel	50.	530049005	Grommet-Knob			
22.	530016080	Screw	51.	530015922	Nut-"U"-Type			
23.	530037817	Starter Pulley	52.	530059701	Assy-Chassis (fuel lines and caps)			Not Shown
24.	530015892	Screw						
25.	530049336	Housing-Fan	53.	530015907	Washer-Thrust			
26.	530069232	Kit-Rope	54.	530047061	Assy-Clutch Drum w/bearing			
27.	530056402	Handle-Starter	55.	530015611	Washer-Clutch	530164938		Manual-Operators
28.	530027531	Spring-Recoil	56.	530014949	Assy. Clutch	530053163		Decal-Warning
29.	530015920	Screw						

REPAIR PARTS

SEARS MODEL 944.414370

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530016153	Screw	23.	530037813	Diffuser- Muffler
2.	530055638	Assy- Cylinder Shield (Incl. #16)	24.	530036103	Screen- Spark Arrestor
3.	530069247	Kit- Fuel Line (Small)	25.	530016132	Bolt- Muffler
4.	530047213	Assy- Air Purge	26.	530047631	Grommet- throttle cable
5.	530015780	Screw	27.	---	Kit- Carburetor
6.	530095646	Assy- Fuel Pick-up		530071820	Zama (W-20)
7.	530047442	Ground Strap		530071821	Walbro (WT-662)
8.	530039198	Ignition Module	(Note: Repair kits are not available for this carburetor)		
9.	530015814	Screw	28.	530069608	Carb. Gasket
10.	530057475	Assy- Wire Harness	29.	530016386	Screw
11.	530037793	Foam- Air Filter	30.	530049700	Adapter- Carb.
12.	530016101	Nut	31.	530016187	Screw
13.	530057702	Assy- Air box (incl. throttle cable)	32.	530069608	Gasket- Carb Adapter
14.	530035526	Grommet	33.	530071408	Kit- Piston (Incl. 34 & 35)
15.	530054144	Seal- Carb Adapter	34.	530038729	Piston Ring
16.	530055698	Reflector- Heat	35.	530015697	Retainer- Piston Pin
17.	Champion	Spark Plug (RCJ-7Y)	36.	530069608	Kit- Engine Gasket (Incl. 21, 28 & 32)
18.	530016136	Clip- High Tension Lead	37.	530031163	Wrench- Bar
19.	530012550	Cylinder	38.	530056363	Assy- Seal & Bearing
20.	530049870	Backplate- Muffler	39.	530037935	Cap- Crankcase
21.	530069608	Gasket- Muffler (kit)	40.	530047062	Assy- Crankshaft
22.	530047207	Assy- Muffler (Incl. 23-25)			

B