


REPAIR PARTS

SEARS MODEL 944.414460



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015957	Screw	24.	530056936	Assy-Chassis	47.	530055406	Shield-Heat
2.	530036491	Cover-Handle	25.	530069572	Kit-Switch	48.	530055322	Clip-"U"
3.	530036097	Trigger-Throttle	26.	530029833	Worm-Oil Pump	49.	530015920	Screw
4.	530036098	Lockout-Throttle	27.	530029835	Hsg.-Oil Pump	50.	530069313	Kit-Starter Pulley
5.	530053443	Lever-Choke	28.	530015896	Screw	51.	530015891	Spring-Recoil
6.	530015937	Screw	29.	530069342	Kit-Clutch Drum	52.	530056939	Housing-Fan
7.	530038985	Spring-Isolator	30.	530015611	Washer-Clutch	53.	530015892	Screw
8.	530036130	Handle-Rear	31.	530014949	Assy-Clutch	54.	530015814	Screw
9.	530015906	Screw	32.	530032119	Bearing-Clutch	55.	530015158	Washer
10.	530038986	Spring-Isolator	33.	530015907	Washer-Thrust	56.	530038327	Handle-Front
11.	530038471	Assy-Throttle Cable (Incl. Grommet)	34.	530029838	Assy-Plunger/Gear	57.	530036113	Front Strap-AV
12.	530069232	Kit-Rope	35.	530029834	Barrel-Oil Pump	58.	530015775	Screw-Plate
13.	530037485	Handle-Starter	36.	530014410	Assy-Oil Pump (Incl. 28, 35, & 36)	59.	530036101	Plate-Isolator
14.	530016080	Screw	37.	530019174	Seal-Oil	60.	530038985	Spring-Isolator
15.	530047667	Plate-Baffle Fan	38.	530037057	Pickup-Oil	61.	530015984	Screw
16.	530016071	Nut-Flywheel	39.	530056533	Filter-Oil	62.	530047855	Bar Plate
17.	530015127	Washer-Flywheel	40.	530016037	Screw	63.	71-3634	Chain 18"
18.	530039147	Assy-Flywheel	41.	530015814	Screw	64.	71-36372	Bar 18"
19.	530036043	Plate-Support (Bar Stud)	42.	530029850	Chain Catcher	65.	530069611	Kit-Bar Adjust (incl. 66,67)
20.	530029868	Plug-Vent	43.	530015877	Bar Bolt	66.	530038593	Retainer
21.	530026119	Valve-Check	44.	530015805	Screw	67.	530015826	Pin-Bar Adjust
22.	530015922	Nut-Speed	45.	530014381	Kit-Spike Assy. (Incl. #44)	68.	530059645	Assy-ChainBrake
23.	530010845	Assy-Fuel Cap	46.	530010846	Assy-Oil Cap	69.	530015917	Nut-Bar Mounting

B